

Warranty

Langer EMV-Technik GmbH shall remedy all defects attributable to material or manufacturing faults within the statutory warranty period by repairing the product or supplying replacement parts.

This guarantee is only granted on condition that:

- the information and instructions in the operating instructions are observed.

The guarantee expires if:

- an unauthorized repair is carried out on the product
- the product is modified
- the product is not used as intended

Customer service

Please contact us if you have any questions, comments or suggestions.

You can contact us:

Monday – Friday
8:00 a.m. – 3:00 p.m.

Contact us at:

Address: Langer EMV-Technik GmbH
Nöthnitzer Hang 31
01728 Bannewitz
Germany

Web: www.langer-emv.de
E-mail: sales@langer-emv.de
Phone: +49 (0) 351-430093-0
Fax: +49 (0) 351-430093-22

Calibration

We recommend having the product calibrated every two years by the manufacturer Langer EMV-Technik GmbH or by a certified service partner..

Declaration of Conformity

Manufacturer:
Langer EMV-Technik GmbH

Nöthnitzer Hang 31
01728 Bannewitz
Germany

Langer EMV-Technik GmbH herewith declares that the

H2 / H3 set, E-field and H-field sources including
BS 02-h, BS 04DB-h, BS 05DB-h, BS 05DU-h, ES 00-H, ES 01-h, ES 02-h,
ES 05D-h, ES 08D-h

conforms with the following relevant regulations:

- Restriction of certain Hazardous Substances 2011/65/EU

The following applicable standards were used to implement the requirements specified by the a forementioned directives:

- IEC 60502-2 – Power cables with extruded insulation for rated voltages 1 kV up to 30 kV
- DIN EN IEC 63000:2019-05 (Restriction of hazardous substances)

Note: This product is not covered by the Low Voltage Directive (2014/35/EU), as the operating voltage exceeds 1000 V AC.

Name of the person authorized to compile the technical documentation:

Katja Langer
Bannewitz, 2026-05-20
Signature:



K. Langer, CEO



LANGER
EMV-Technik

H2 set and H3 set E- and B-field sources



Scan Now: User Manual

https://www.langer-emv.de/downloads/H2_H3_set

Safety instructions

When using a product from LANGER EMV-Technik GmbH, please observe the following safety instructions to protect yourself from electric shock or the risk of injuries.

Read and follow the operating instructions and keep them in a safe place for later consultation. The device may only be used by personnel who are qualified in the field of EMC and who are fit to work under the influence of disturbance voltages and (electric and magnetic) burst fields.

- Never use any damaged or defective devices.
- Carry out a visual check before using a measurement set-up with a Langer EMV-Technik GmbH product. Replace any damaged connecting cables before starting the product.
- Never leave a Langer EMV-Technik GmbH product unattended whilst this is in operation.
- The Langer EMV-Technik GmbH product may only be used for its intended purpose. Any other use is prohibited.
- Observe the operating and safety instructions for all devices used in the set-up.
- People with a pace-maker are not allowed to work with this device.
- The test set-up should always be operated via a filtered power supply.

Attention! Functional near fields and interference emissions may occur when operating Pulse- and RF generators or in connection with field sources. The user is responsible for taking measures to protect the correct function of products outside the EMC environment of the test set-up (in particular against interference).

This can be achieved by:

- observing an appropriate safety distance,
- use of shielded or shielding rooms.
- The disturbances that are injected into the modules can destroy the device under test (latch-up) if their intensity is too high. Protect the device under test by:
 - increasing the disturbance gradually and stopping when a functional fault occurs,
 - interrupting the power supply to the device under test in the event of a latch-up.

Attention! Make sure that internal functional faults are visible from outside. The device under test may be destroyed due to an increase in the injection intensity if the faults are not visible from outside. Take the following measures as necessary:

- monitor representative signals in the device under test with optical sensors
- special test software
- visible reaction of the device under test to inputs (reaction test of the device under test).

We cannot assume any liability for the destruction of devices under test!

Warranty

Langer EMV-Technik GmbH shall remedy all defects attributable to material or manufacturing faults within the statutory warranty period by repairing the product or supplying replacement parts.

This guarantee is only granted on condition that:

- the information and instructions in the operating instructions are observed.

The guarantee expires if:

- an unauthorized repair is carried out on the product
- the product is modified
- the product is not used as intended



Information on Recycling and Disposal

In accordance with the WEEE Directive 2012/19/EU (Waste Electrical and Electronic Equipment), the following must be observed:

At the end of its service life, this product should be taken to a suitable disposal facility for recycling and disposal. Do not dispose of with household waste.



Scan Now: User Manual

https://www.langer-emv.de/downloads/H2_H3_set