



### Short description

PT 4型猝发变压器按照IEC 61000-4-4标准从发电机中分离出EFT/爆冲发生器的输出脉冲。它发出的对称的输出信号能以不同的路径耦合到受测物上。经过测试，可以确定与受测物上单个印刷电路板或插接件相对应的故障。

Within the PT4 Fi connection cable there are damping elements, which insulate even high frequency common mode current from EFT/burst generator in the device under test as far as possible.

PT4 Fi is delivered with Fischer connector.

### Technical parameters

|         |                       |
|---------|-----------------------|
| 变换系数    | 1:1                   |
| 输出端耐压强度 | 500 V / DC, AC 50 Hz  |
| 输出接口    | Fischer plug S103A023 |

### Application with PT4 and GP 23 and OSE 150 set

